

ELEV 212

NZNE

AUCKLAND APPROACH: 124.3 129.5

AWIB: 130.45

NORTH SHORE**ARRIVAL**

WHENUAPAI TOWER: 134.5 119.9

UNATTENDED: 118.0

Arrival Procedures

Flight Plan to North Shore via Whenuapai.

Non-RNP aircraft

- Make instrument approach at Whenuapai, thence proceed VFR to North Shore.

RNP aircraft

- Insert "REQ RNP NE" on flight plan.
- Request a RNP approach at North Shore from Auckland Approach 124.3 MHz prior to 30 DME Auckland.
- Report when established on RNP approach, thence follow Common Frequency Zone radio procedures.
- Maintain a listening watch on approach frequency 124.3 MHz using second radio until otherwise instructed, or the aircraft has landed.

CAUTION: These procedures take aircraft through the North Shore, Whenuapai and Woodhill GAAs.

ELEV 212

CAT A,B

NZNE

AUCKLAND APPROACH: 124.3 129.5

WHENUAPAI TOWER: 134.5 119.9

AWIB: 130.45

UNATTENDED: 118.0

