

ELEV 100

OMAKA

NZOM

VFR ARRIVAL/DEPARTURE PROCEDURES (3)

WOODBOURNE TOWER: 122.8 118.1

WOODBOURNE ATIS: 126.05

Departure Procedures

During daylight hours remain in Omas VFR transit lane T654, or obtain clearance from Woodbourne Tower prior to entering controlled airspace.

The following departure procedures may be issued by Woodbourne Tower for use in the Woodbourne CTR/D:

- ③ Rivers Departure: Track via T654 1500 ft or below to enter CTR at Circles.
 Leave CTR west of Waihopai River and/or north of Wairau
 River 2500 ft or below.
- ④ Taylor Departure: Track via Taylor Dam until clear of CTR/D at 2500 ft or
 below.

Communications Failure

Within the Omas VFR Transit Lane NZT654 — during daylight hours continue to operate in the Omas VFR Transit Lane NZT654.

Within Woodbourne CTR/D — follow assigned clearance, **Squawk 7600**.

