

Non-Certificated Water Aerodrome,
Auckland Harbour

AUCKLAND HARBOUR

NZAW

SEA LEVEL

OPERATIONAL DATA

UNATTENDED: 120.4

OPERATIONAL REQUIREMENTS

1. Under maritime Rule Part 22, all seaplanes are deemed to be a vessel when operating on the water.
2. No operator or pilot may operate onto the aerodrome without first obtaining from the Auckland Harbourmaster (C/- Auckland Harbourmaster Office, Tel (09) 362 0397, Private Bag 92250, Auckland 1142, or email harbourmaster@aucklandtransport.govt.nz) an exemption from Auckland Council Navigation Safety Bylaw 2014 clause 35(2), and map 7.0 Area reserved as the Waitemata Harbour Restricted Zone.
3. No operator or pilot may operate onto the aerodrome without first obtaining written approval from the aerodrome operator (Auckland Seaplanes), a full briefing of limits, restrictions and other control measures, which are from time to time necessary for the proper use of the public harbour and the protection of persons, property and interaction with other harbour users.
4. MBZ procedures apply to all operations within Auckland MBZ area.

FACILITIES

Nil

SUPPLEMENTARY

Operator: Auckland Seaplanes, 11 Brigham Street, Auckland Central
Tel (09) 390 1121
Email: info@aucklandseaplanes.com

Available for limited use subject to prior agreement and written approval from the operator.

