

NZNS

**STANDARD ROUTE CLEARANCES**

For flights departing Nelson Airport:

<b>ADES</b>	<b>Designator</b>	<b>Route</b>
AA	NSAA3	RWY 02 — Q438 IGUTA Y175 OMKUN Y311 DADUK Y273 PEPPE H182.
CH	NSCH2	RWY 20 — PAVNI Y341 SEBRU Y655 OMKUN Y311 DADUK Y273 PEPPE H182
HN	NSHN3	Q787 ALADA Y894
PM	NSPM1	RWY 02 — Q438 IGUTA Y175 OPABI Q126 RWY 20 — PAVNI Y341 SEBRU Y655 OMKUN Y175 OPABI Q126
<b>D</b> PP	NSPP3	Q438 SNAPA Y501 DUMOT H240 (10,000 ft and above)
WU	NSWU2	H267 SIMZI Q388
WN	NSWN2	RWY 02 — H240 DUMOT Q367 RWY 20 — Q438 SNAPA Y501 DUMOT Q367
WB	NSWB3	H267❶ H133

Where specified the following applies:

- ❶ Non-RNAV aircraft expect radar vectors after SIMZI.

The designator will be used in a route clearance to indicate the route that is to be flown. A full route clearance will be issued to flights for destinations and/or routes not covered by these standard route clearances.

**Communication****Arriving Aircraft — IFR**

Arriving aircraft to remain on TOWER frequency until parked.

**Departing Aircraft — IFR**

- Call DELIVERY up to a maximum 15 minutes prior to start for route clearance, advising stand number or location on aerodrome, requested level, alternate, receipt of ATIS and QNH.
- ATC clearance will be issued after flight plan handling is complete, normally within 2 minutes.
- When ready call DELIVERY for start approval and advise POB. Any start delay will be advised at this time.
- Call TOWER for taxi clearance and departure instructions.
- When airborne remain on Nelson TOWER frequency until instructed.

