

ELEV 23

NZAA

TOWER: 118.7 120.95

APRON: 123.0

AUCKLAND**GROUND MOVEMENTS (10) — CODE F ACFT**

DELIVERY: 128.2

ATIS: 127.8 127.0

GROUND: 121.9

The following information is code F aircraft specific and is to be used in conjunction with Auckland Code F ACFT Taxi Routes — RWY 05R/23L — Arrival and Auckland Code F ACFT Taxi Routes — RWY 05R/23L — Departure charts. A380, 748 and AN124 aircraft types are restricted to the routes depicted on the code F taxi route charts.

Code F Taxi Information

- TWY A2, A3 and A8 are available for approved A380 operators in accordance with A380 supplementary procedures
- Outer engines may overhang the grass on TWY A1, A9 and B between B1 and B2
- TWY B between B2 and B6 is not available
- RWY 05R/23L west of TWY A10 is available for code F operations
- Code F aircraft cannot taxi behind a code D, E or F aircraft holding on TWY A1A to TWY A10 inclusive
- When a code F aircraft is on TWY A between B2 and J a code E aircraft can operate on TWY B
- When a code F aircraft is on TWY B between TWY B6 and J, TWY D and S84 are restricted to MAX code C.

ELEV 23

NZAA

TOWER: 118.7 120.95

APRON: 123.0

AUCKLAND**GROUND MOVEMENTS (11) — CODE F ACFT**

DELIVERY: 128.2

ATIS: 127.8 127.0

GROUND: 121.9

Dual Code F Aircraft Operations

- Code F aircraft are not allowed on TWY A between TWY B6 and J and on TWY B between TWY B6 and J at the same time
- Simultaneous movement of code F aircraft on TWY D8 and on TWY K between TWY B and aircraft stand 7 are not permitted
- Simultaneous code F aircraft operations on RWY 05R/23L with another code F aircraft on TWY A is permitted

Stand Information

- Contact stands for code F aircraft are 10, 15 and 16. These stands are equipped with dual airbridges, ground power, air conditioning and NIGS
- Remote stands for code F aircraft are 17, 18, 19, 74, 75, 78, 79 and 83
- The A380 must be towed onto S78, 79 and 83
- Code F aircraft using stand 83 should follow the white lead-in line
- Code F aircraft assigned stand 83 cannot taxi on TWY J north of aircraft stand 6
- Code F aircraft on stand 83 must push back south to start on stand 84 or at SPOT 2
- TWY B will be restricted to maximum code D (767 type aircraft) when a code F is on Stand 84