

Non-Certificated Aerodrome 3 NM SE of
Manurewa**ARDMORE**

NZAR

OPERATIONAL DATA (1)**RWY**

RWY	SFC	Strength	Gp	Slope	ASDA	Take-off distance			LDG DIST
						1:20	1:30	1:40	
03 21	B	PCN 14 F/D/X/T	8	Nil	1411	1299 1306		1299 1306	1306 1299
03 21	Gr	ESWL 1143	3	Nil	518	518			518
07 25	Gr	ESWL 1143	4	0.3U 0.3D	597	597			597

MINIMA

IFR Take-off		
RWY	Day	Night
03	1000-1500	1000-5
21	300-1500	300-1500

LIGHTING

PAL 118.1

To activate: transmit 5 pulses over a 3-4 second period. If runway lights fail to activate, keep clicking transmit up to 10 times until lights turn on. Joining aircraft may not be able to see lights if left on low intensity.

To change intensity: transmit similar 5 pulses but hold the 5th until desired intensity reached, then stop transmission.

Runway: 03/21 APAPI 3.0°/TCH 46, LIL RWY
RWY edge light spacing — 60 m

Aerodrome: ABN ALTN FLG GW 2.5 SEC, WDI ABM THR RWY 21

Taxiway to SE apron, TWY M and TWY J marked with CL green reflectors.

No standby power available.

FACILITIES

UNICOM: Outside Daylight Saving During Daylight Saving
2000 to 0600 daily 1900 to 0500 daily
Tel (09) 296 4512 Fax (09) 296 4514

AFRU provides confirmation of radio frequency and equipment serviceability during daylight hours. UNICOM also provides guidance for pilots unfamiliar with Ardmore and arranging refuelling, taxis etc on request.

Fuel: Avgas 100, Carnet, BP Auckland Aero Club (09) 299 8590
Jet A1, Swipecard, BP NZ Warbirds (09) 296 1535
Jet A1, Swipecard, BP western corner of south east apron
Z Energy, Z card Ardmore Flying School (09) 298 5055
Z Energy Avgas and Jet A1 into aircraft by tanker via Z card 0800-1700 daily
Other times by arrangement, VHF 133.10 or 021 369 600
Z Energy Avgas 100, Z Energy Jet A1, South Eastern Apron (southern corner)
available at Z Air Stop via Z card.

Repairs

RFS: 25 kg Dry Powder/BCF extinguisher available under the UNICOM tower stairs.

(Continued)

Effective: 13 SEP 18

ARDMORE
OPERATIONAL DATA (2)**SUPPLEMENTARY**

Operator: Ardmore Airport Limited, Ardmore Aerodrome,
PO Box 72253, Papakura 2244

Facilities Manager: Tel (09) 298 9544 Fax (09) 298 6213.

For details of local procedures and noise abatement requirements refer to Ardmore Airport Operations Manual, available on <http://www.nzar.co.nz>

Facility Fees

Facility fees are payable to the operator. Current rates are available at www.nzar.co.nz