
ELEV 26 NZWU

WHANGANUI

AERODROME (1)

UNICOM/UNATTENDED: 120.2



1. Circuit: RWY 08, 11, 14 - Aircraft right hand Helicopter left hand RWY 26, 29, 32 - Aircraft left hand Helicopter right hand

Helicopter circuit height 800 ft maximum

- 2. Helicopters are required to air taxi on all designated taxiways and terminal parking areas.
- 3. Simutaneous take-offs and/or landings are prohibited.

4. CAUTION:

- All grass movement areas may be soft and braking action may be poor during and after periods of rain or showers.
- Transition from apron to TWY D4 is rough. Aircraft with low propellor clearance should exercise caution.
- Multiple bird hazards at times.
- 5. Extensive fixed and rotary wing training being carried out at all times on and adjacent to the
- Aircraft are NOT to be left unattended on the apron unless approved by the Airport Duty Officer on Tel (06) 349 3199 or UNICOM (06) 349 3166 when on watch.

(continued)

WHANGANUI AERODROME (2)

- Terminal Spots 1 and 2 are reserved for scheduled operations. May be booked for charter services by calling the Airport Duty Officer on Tel (06) 349 3199.
- Casual parking is restricted. Contact the Airport Duty Officer on Tel (06) 349 3199 or UNICOM when on watch.
- 9. Grass area parking park to the east of the apron area well clear of the BP Jet A1 bowser.
- Parking restrictions aircraft less than 2500 kg should park within the grassed parking areas.
- 11. TWY W for NZICPA use only.
 - 12. Grass area parking to the west of the apron area for NZICPA use only.
 - 13. Helicopters conducting arrivals or departures on the south side of the aerodrome must conform with fixed wing procedures.
 - 14. Aerobatics or air displays are not permitted at the aerodrome below 2000 ft unless with the prior permission of the aerodrome operator.
 - 15. U-turns on RWY 11/29 by aircraft heavier than 5700 kg MCTOW permitted only at runway ends.